


TEMPLATE

1 FOLD HERE ON DOOR EDGE

2 MARK FOR $1\frac{3}{4}$ " (45mm) DOOR

MARK FOR $1\frac{3}{8}$ " (35mm) DOOR



3 THEN DRILL 1" (25mm) HOLE IN CENTER DOOR OF EDGE

FOR INSTALLING ENTRY LOCK AND DEADBOLTS

$2\frac{3}{8}$ " (60mm) BACKSET



$2\frac{3}{4}$ " (70mm) BACKSET



IMPORTANT!
PLACE TEMPLATE ON HIGH EDGE OF DOOR BEVEL

4 MARK CENTER OF HOLE ON DOOR FACE



5 DRILL 2-1/8" (54mm) HOLE

