

TEMPLATE

1

**FOLD HERE ON
DOOR EDGE**

2

MARK
FOR
1-3/4"(45mm)
DOOR

MARK
FOR
1-3/8"(35mm)
DOOR

3

THEN DRILL 1"(25mm) HOLE
IN CENTER DOOR OF EDGE

2"(51mm) IN DEPTH

FOR INSTALLING
ENTRY LOCK AND DEADBOLTS

2-3/8"(60mm) BACKSET

2-3/4"(70mm) BACKSET

IMPORTANT!
PLACE TEMPLATE
ON HIGH EDGE OF
DOOR BEVEL

4

MARK CENTER
OF HOLE ON
DOOR FACE

5

DRILL
Ø2-1/8"(54mm)
HOLE

